

Frame Heaters

EFHJO-19AT

Frame heater, digital screen



Features	<ul style="list-style-type: none"> • Ceramic heating, heating uniformly, heat transfer is fast. • Wool felt protection, temperature does not leak, save power, heat insulation, it's safe to use and long time life • Digital screen • Temperature adjustment
Voltage	AC220V/110V
Frequency	50HZ/60HZ
Power	800w
Temperature	80°C - 160°C
Product Size	19cm x 15cm x 16cm (L x W x H)
Weight	1.1kg



EFHJO-6AT

Frame heater

Features	<ul style="list-style-type: none"> • Quick heating • Strong air output • Uniform heating
Voltage	AC220V/110V
Frequency	50HZ/60HZ
Power	500w
Temperature	Cold air - 130°C
Air Flow Rate	2.0m/s - 4.0m/s
Weight	1kg

EFHJO-201C

Frame heater, digital screen



Features	<ul style="list-style-type: none"> • The frame heater is a hot air blower which softens frames made of celluloid and similar materials • Air ventilation can be changed as desired • Double power resitancy • Two temperature settings 75°C and 140°C • Heat resistant plastic vents and top • Heat resistant plastic concentrator included • Safety thermal cut-out switch
Voltage	AC220V/110V
Frequency	50HZ/60HZ
Power	900w
Temperature	75°C - 140°C
Product Size	20cm x 14.4cm x 21.3cm (L x W x H)
Weight	1.6kg

Frame Heaters



EFHJO-6C
Frame heater

Features	<ul style="list-style-type: none"> • Quick heating • Strong air output • Uniform heating • Temperature adjustment
Voltage	AC220V/110V
Frequency	50HZ/60HZ
Power	500-650w
Temperature	70°C - 110°C
Product Size	15.6cm x 12.0cm x 22.50cm (L x W x H)
Weight	0.75kg



EFHJO-320
Frame heater

Features	<ul style="list-style-type: none"> • Quick heating • Strong air output • Uniform heating • Temperature adjustment
Voltage	AC220V/110V
Frequency	50HZ/60HZ
Power	500w
Temperature	80°C - 110°C
Product Size	31cm x 13.5cm x 19cm (L x W x H)
Weight	1.4kg

Attention

1. Please don't heat over 30mins for one time.
2. When voltage is not stable, please don't use the machine.
3. Please don't drop in water inside the machine, or it will burn up the machine.
4. Please check whether there is anything in air outlet before using.
5. Frame heater should be put on flat table, make sure there is nothing block air intake.