


### Reading 1.25 Shift 1.25



Please Note: Measurements are not to scale


- ORDER AS READING RX
- POWER DECREASES FROM READING AREA

**OPTIC** 

- SHIFT AREA STARTS BELOW LOWER LID
- PUPIL CENTRE = 60% OF SHIFT POWER
- FULL SHIFT STARTS ABOVE UPPER LID



#### Plano 0.00 Add 1.25




- ORDER AS DISTANCE RX WITH READING ADDITION
- ADD RANGE IS +0.25 TO +2.50
- ORDER THE ADD IN PLUS POWER
- INTERMEDIATE ZONE STARTS 2MM BELOW PUPIL CENTRE
- POWER CONTINUES TO INCREASE BELOW PUPIL HEIGHT



## INFINITY 3D MAXIMA

#### Plano 0.00 Add 1.50




- ORDER AS DISTANCE RX WITH READING ADDITION
- ADD RANGE IS +0.75 TO +3.50
- ORDER THE ADD IN PLUS POWER
- INTERMEDIATE ZONE STARTS 4MM BELOW PUPIL CENTRE
- POWER CONTINUES TO INCREASE BELOW PUPIL HEIGHT



# INFINITY 3D MULTIVIEW

#### Plano 0.00 Add 1.50




- ORDER AS DISTANCE RX WITH READING ADDITION
- ADD RANGE IS +0.75 TO +3.50
- ORDER THE ADD IN PLUS POWER
- INTERMEDIATE ZONE STARTS 4MM BELOW PUPIL CENTRE
- POWER CONTINUES TO INCREASE BELOW PUPIL HEIGHT



# INFINITY 3D OUTDOOR

#### Plano 0.00 Add 1.50




- ORDER AS DISTANCE RX WITH READING ADDITION
- ADD RANGE IS +0.75 TO +3.50
- ORDER THE ADD IN PLUS POWER
- INTERMEDIATE ZONE STARTS 4MM BELOW PUPIL CENTRE
- POWER CONTINUES TO INCREASE BELOW PUPIL HEIGHT



## INFINITY 3D I-ZONE

#### Plano 0.00 Add 1.50



- ORDER AS DISTANCE RX WITH READING ADDITION
- ADD RANGE IS +0.75 TO +3.50
- ORDER THE ADD IN PLUS POWER
- INTERMEDIATE ZONE STARTS 4MM BELOW PUPIL CENTRE
- POWER CONTINUES TO INCREASE BELOW PUPIL HEIGHT

